

Barbasol[®]

Rechargeable Foil Shaver



USE AND CARE GUIDE

(For model: CBF1-2002)

Manufactured under exclusive license of Perio Inc. ©Barbasol

PLEASE RETAIN THIS USE & CARE GUIDE FOR FUTURE REFERENCE

When using an electrical appliance, basic precautions should always be observed. Read all instructions before using this shaver.

DANGER


To reduce the risk of electric shock:

1. Do not reach for an appliance that has fallen into water. Unplug it immediately.
2. Do not charge while bathing or in shower.
3. Do not charge this unit near a tub, toilet or sink.

WARNING/IMPORTANT

1. Read the instruction manual thoroughly before using the device.
2. Use the shaver only for purposes described in this instruction book.
3. For hygienic reason, the shaver should not be shared with others.
4. This appliance is not intended for use by persons (including children) with reduced physical sensory or mental capabilities, or lack of experience and knowledge.
5. Regularly check the foil condition, if signs of damage are visible, do not use.
6. Do not use if skin is red, irritated, inflamed, infected or blistered.
7. Foils and blades will wear over time and may require replacing.
8. This product is for household use only.
9. Do not place or store your unit in direct sunlight. Store only in a cool dry place.
10. Keep your unit out of reach of children.
11. Do not charge the shaver where the temperature is below (32 °F), or higher than (100°F), or where it will be exposed to direct sunlight or a heat source, or near excessive moisture.
12. Use the included charging adaptor only.
13. Dry the shaver completely before charging it.
14. Keep the charging cord away from water and handle with dry hands.
15. Do not pull, twist, or severely bend the cord.
16. Do not wrap the power cord tightly around the appliance.
17. Do not take the housing apart.

DESCRIPTION OF THE APPLIANCE



CHARGING

1. Prior to first use, charge for 12 hours.
2. Regular Shaving will require 12 hours charging time for 60 minutes of runtime. Usage time may decrease over time.
3. Do not overcharge, as this may damage the battery life.
4. The shaver will not charge when it is switched on. Be sure to check that the "On/Off switch" is set to "Off" when charging.

HOW TO USE

1. Switch on by pushing the on/off switch.
2. Hold the shaver at a right angle to your skin.
3. Apply gentle pressure as you move the shaver across your face, stretching the skin with your free hand. Move the shaver back and forth to achieve desired result.
4. Applying excessive pressure will not result in a closer shave and may cause irritation or skin damage.
5. To use the beard trimmer, slide the trimmer handle up to open the trimmer, place the trimmer at a right angle to your skin and move it downward to trim sideburns.



**INFORMATION ON WASTE DISPOSAL FOR CONSUMERS OF
ELECTRICAL & ELECTRONIC EQUIPMENT**

NOTE! The battery the appliance is equipped with contains substances, which may result in environmental pollution.

Before disposal of the appliance remove the battery.

Do not dispose of the appliance. Please take all WEEE marked waste to your local recycling center for proper disposal.

2 Year Limited Warranty

Questions: call toll-free at (844)-777-9601

Email Support: support@barbasolelectric.com

This product is covered under warranty for a period of 2 years from the purchase date. Improper use or failure to follow operation and instruction guide will void this warranty.

Do not return to the store. Please send a proof of purchase, return label with your name and address, along with a check for \$4.95 to cover S/H. Please allow 6-8 weeks to process your return.

Make check payable to Xtreme Personal Care, Inc.

Clip & Return to:

Xtreme Personal Care

32 Brunswick Ave.

Edison NJ 08817

Attention: Customer Service

Customer Name _____

Return Address _____

Date Purchased _____

Store _____

Brief Description of Issue _____