

# ***Barbasol***<sup>®</sup>

## **Rechargeable Rotary Shaver**



### **USE AND CARE GUIDE**

(For model: CBR1-1002)

**Manufactured under exclusive license of Perio Inc.©Barbasol**

**PLEASE RETAIN THIS USE & CARE GUIDE FOR FUTURE REFERENCE**

When using an electrical appliance, basic precautions should always be observed.  
Read all instructions before using this shaver.

**DANGER**

To reduce the risk of electric shock:

1. Do not reach for an appliance that has fallen into water. Unplug it immediately.
2. Do not use while bathing or in the shower.
3. Do not charge this unit near a tub, toilet or sink.
4. USE ONLY in dry condition.
5. Do not submerge in water.

**WARNING/IMPORTANT**

1. Read the instruction manual thoroughly before using the device.
2. Use the shaver only for purposes described in this instruction book.
3. For hygienic reasons, the shaver should not be shared with others.
4. This appliance is not intended for use by persons (including children) with reduced physical sensory or mental capabilities, or lack of experience and knowledge.
5. Regularly check the foil condition, if signs of damage are visible, do not use.
6. Do not use if skin is red, irritated, inflamed, infected or blistered.
7. Foils and blades may wear over time and may require replacing.
8. Household use only.
9. Do not place or store your unit in direct sunlight. Store only in a cool dry place.
10. Keep your unit out of reach of children.
11. Do not charge the shaver where the temperature is below (32 °F), or higher (100°F), or where it will be exposed to direct sunlight or a heat source, or near excessive moisture.
12. Use the included charging cord only.
13. Dry the shaver completely before charging it.
14. Keep the charging cord away from water and handle with dry hands.
15. Grip the plug when disconnecting it from an AC outlet, tugging on the power cord may damage it. Store the cord in a dry area where it will be protected from damage.
16. Do not pull, twist, or severely bend the cord.
17. Do not wrap the power cord tightly around the appliance.
18. Do not take the housing apart.

## CHARGING

1. Before first use, charge for 12 hours.
2. Regular shaving will require 8 hours charge time, for 45 minutes runtime. Usage time may decrease over time.
3. Do not overcharge, as this will damage the battery life.
4. Ensure shaver is powered off prior to plugging in the charging cord.



## HOW TO USE

1. Switch on by pushing the on/off switch.
2. Hold the shaver at a right angle to your skin.
3. Apply gentle pressure as you move the shaver across your face, stretching the skin with your free hand. Move the shaver back and forth to achieve desired result.
4. Applying excessive pressure will not result in a closer shave and may cause irritation or skin damage.
5. To use the beard trimmer, slide the trimmer handle up to open the trimmer, place the trimmer at a right angle to your skin and move it downward to trim sideburns.

## **HOW TO CLEAN**

Clean the appliance after each use to ensure continued performance.

DO NOT submerge the unit in liquid.

DO NOT use abrasive liquids or detergents.

DO NOT clean while attached to charging cable.

Wipe off any moisture from the shaver with a soft dry cloth.

DO NOT replace the protective cap until the outer foil is completely dry.

## **BRUSH CLEANING**

Squeeze the system outer foil release buttons and lift the system outer foil upward to remove it.

Remove the inner blade, one at a time, by grasping them firmly at both ends and pulling straight away from the shaver.

Clean the outer foils, the inner blade and the trimmer with the brush provided.



## **INFORMATION ON WASTE DISPOSAL FOR CONSUMERS OF ELECTRICAL & ELECTRONIC EQUIPMENT**

This mark on a product and/or accompanying documents indicates that when it is to be disposed of, it must be treated as Waste Electrical & Electronic Equipment (WEEE). Any WEEE marked waste products must not be mixed with general household waste, but kept separate for treatment, recovery, and recycling of the material used.

For proper treatment, recovery, and recycling: please take all WEEE marked waste to your local recycling center.

# 2 Year Limited Warranty

Questions: call toll-free at (844)-777-9601

Email Support: [support@barbasolelectric.com](mailto:support@barbasolelectric.com)

This product is covered under warranty for a period of 2 years from the purchase date. Improper use or failure to follow operation and instruction guide will void this warranty.

Do not return to store. Please send a proof of purchase, return label with your name and address, along with a check for \$4.95 to cover S/H. Please allow 6-8 weeks to process your return.

Make check payable to Xtreme Personal Care, Inc.

Clip & Return to:

Xtreme Personal Care

32 Brunswick Ave.

Edison NJ 08817

Att: Customer Service

Customer Name \_\_\_\_\_

Return Address \_\_\_\_\_

Date Purchased \_\_\_\_\_

Store \_\_\_\_\_

Brief Description of Issue \_\_\_\_\_