

Barbasol[®]

Rechargeable Beard Trimmer



USE AND CARE GUIDE

(For model: CBT1-3002)

Manufactured under exclusive license of Perio Inc.©Barbasol

PLEASE RETAIN THIS USE & CARE GUIDE FOR FUTURE REFERENCE

When using an electrical appliance, basic precautions should always be observed. Read all instructions before using this trimmer.

DANGER

To reduce the risk of electric shock:

1. Do not reach for an appliance that has fallen into water. Unplug it immediately.
2. Do not use while bathing or in the shower.
3. Do not charge this unit near a tub, toilet or sink.
4. USE ONLY in dry condition.
5. Do not submerge in water.

WARNING/IMPORTANT

1. Read the instruction manual thoroughly before using the device.
2. Use the shaver only for purposes described in this instruction book.
3. For hygienic reason, the shaver should not be shared with others.
4. This appliance is not intended for use by persons (including children) with reduced physical sensory or mental capabilities, or lack of experience and knowledge.
5. Regularly check the foil condition, if signs of damage are visible, do not use.
6. Do not use if skin is red, irritated, inflamed, infected or blistered.
7. Blades will wear over time and may require replacing.
8. Household use only.
9. Do not place or store your unit in direct sunlight. Store only in a cool dry place.
10. Keep your unit out of reach of children.
11. Do not charge the trimmer where the temperature is below (32°F), or higher than (100°F), or where it will be exposed to direct sunlight or a heat source, or near excessive moisture.
12. Use the included charging cord only.
13. Dry the shaver completely before charging it.
14. Keep the charging cord away from water and handle with dry hands.
15. Grip the plug when disconnecting it from an AC outlet, tugging on the power cord may damage it. Store the cord in a dry area where it will be protected from damage.
16. Do not pull, twist, or severely bend the cord.
17. Do not wrap the power cord tightly around the appliance.
18. Do not take the housing apart.

CHARGING

1. Before first use, charge for 12 hours.
2. Regular shaving will require 8 hours charge time, for 30 mins runtime. Usage time may decrease over time.
3. Do not overcharge, as this may affect battery life.
4. Ensure Beard Trimmer is switched off prior to plugging the charging cord into AC socket.



HOW TO USE THE APPLIANCE

This appliance can be also operated with alkaline battery, do not charge it when using alkaline battery.

- Before cutting make sure the head of the person, whose hair is to be cut, is at your chest level.
- To obtain best results use the appliance when hair is dry.
- Move the appliance in opposite direction of the hair growth.

CUTTING WITH GUIDE

1. Adjust the cutting guide up to 5 settings by pushing plastic comb up or down with your thumb.
2. Two built-in adjustable settings on switch for short or very short stubble.

CLEANING AND MAINTENANCE ACTIVITIES

1. Clean the appliance after each use.
2. To clean the appliance, do **not** use any liquids such as alcohol.
3. Make sure the appliance has been switched off and the charging cord is unplugged.
4. Remove the cutting guide and use brush provided.



ENVIRONMENT PROTECTION

The battery in the appliance contains substances, which may result in environmental pollution. Before disposal of the appliance remove the battery. Please take all WEEE marked waste to your local recycling center for proper disposal.

2 Year Limited Warranty

Questions: call toll-free at (844)-777-9601

Email Support: support@barbasolelectric.com

This product is covered under warranty for a period of 2 years from the purchase date. Improper use or failure to follow operation and instruction guide will void this warranty.

Do not return to the store. Please send a proof of purchase, return label with your name and address, along with a check for \$4.95 to cover S/H. Please allow 6-8 weeks to process your return.

Make check payable to Xtreme Personal Care, Inc.

Clip & Return to:

Xtreme Personal Care

32 Brunswick Ave.

Edison NJ 08817

Att: Customer Service

Customer Name _____

Return Address _____

Date Purchased _____

Store _____

Brief Description of Issue _____