

# ***Barbasol***®

## **Wet Power Single Blade**



USE AND CARE GUIDE

(For model :CBT1-3102-BLB)

Manufactured under exclusive license of **Perio Inc.© Barbasol**

**PLEASE RETAIN THIS USE & CARE GUIDE FOR FUTURE REFERENCE**

**When using an electric appliance, basic precautions should always be observed. Read all instructions before using this appliance.**

**DANGER**

**To reduce the risk of electric shock:**

- 1. Do not reach for an appliance that has fallen into water. Unplug it immediately.**
- 2. Do not charge this unit near a tub, toilet or sink.**
- 3. Do not submerge in water.**

**WARNING/IMPORTANT**

1. Read this Use & Care Guide thoroughly before using the device.
2. Use this appliance only for purposes described in this instruction book.
3. For the hygienic reasons, this appliance should not be shared with others.
4. This appliance is not intended for use by persons (including children) with reduced physical sensory or mental capabilities, or lack of experience and knowledge with appliances of this type.
5. Regularly check the blades condition, if signs of damage are visible, do not use.
6. Do not use if skin is red, irritated, inflamed, infected or blistered.
7. Blades may wear over time and may require replacing.
8. For household use only.
9. Do not place or store this appliance in direct sunlight. Store only in a cool dry place.
10. Keep this appliance out of reach of children.
11. Do not charge this appliance where the temperature is below (32°F), or higher (100°F), or where it will be exposed to direct sunlight or a heat source, or near excessive moisture.
12. Use the included charging cord only.
13. Dry this appliance completely before charging it.
14. Keep the charging cord away from water and handle with dry hands.
15. Grip the plug when disconnecting it from an AC outlet, tugging on the charging cord may damage it. Store the cord in a dry area where it will be protected from damage.
16. Do not pull, twist, or severely bend the cord.
17. Do not wrap the power cord tightly around the appliance.
18. Do not take the housing apart.

## **CHARGING**

1. Ensure that the appliance is switched off.
2. Ensure the appliance is in a stable position.
3. Connect the charging cord on the charging connection of the appliance.
4. Connect the other end of the charging cord to a USB charger.
5. The indicator light on the appliance will turn red when charged, and it will turn green after fully charged.
6. Regular shaving will require 2 hours charge time, for 60 minutes run time. Usage time may decrease over time.
7. Do not overcharge, as this will damage the battery life.
8. Ensure this appliance is powered off prior to plugging in the charging cord.



### Trimming with comb

- The precision trimming comb allows you to trim hair to different lengths.

When you trim for the first time, start at the highest length setting to familiarize yourself with the product.

- The settings on the wheel correspond to the remaining hair length after trimming in millimeters. You can select a length from 0.5mm to 10mm.

- Place the front part of the comb onto the blade and push the projection at the back of the comb

## **HOW TO USE**

- 1. Switch on by pushing the on/off switch.**
- 2. Hold the single blade at a right angle to your skin.**
- 3. Apply gentle pressure as you move the single blade across your face, stretching the skin with your free hand. Move the single blade back and forth to achieve desired result.**
- 4. Applying excessive pressure will not result in a closer shave and may cause irritation or skin damage.**

## **Specifications:**

- Waterproof IPX5
- Power Consumption: 5W
- Motor Voltage: 3.2V
- Battery Capacity: Li-ion battery 500mAh x 1
- With charging indicator light.
- Charging: red color; while off once full charged.
- Charged with USB charging cable (0.5m)
- Input: DC 5V 1A
- Charging Time: 2 hours
- Working Time: 1 hour

## **HOW TO CLEAN**

**Clean the appliance after each use to ensure continued performance.**

**DO NOT submerge the unit in liquid.**

**DO NOT use abrasive liquids or detergents.**

**DO NOT clean while attached to charging cable.**

**Wipe off any moisture from the shaver with a soft dry cloth.**



## INFORMATION ON WASTE DISPOSAL FOR CONSUMERS OF ELECTRICAL & ELECTRONIC EQUIPMENT

This mark on a product and/or accompanying documents indicates that when it is to be disposed of, it must be treated as Waste Electrical & Electronic Equipment ((WEEE). Any WEEE marked waste products must not be mixed with general household waste, but kept separate for treatment, recovery and recycling of the material used.

For proper treatment, recovery and recycling: please take all WEEE marked waste to your local recycle center.

### 2 Year Limited Warranty

Questions: call toll-free at (844)- 777-9601

Email Support: [support@barbasolelectric.com](mailto:support@barbasolelectric.com)

This appliance is covered under warranty for a period of 2 years from the purchase date. Improper use or failure to follow operation and instruction guide will void this warranty. Do not return to store. In the event of a damaged product, please send back product with a proof of purchase, return label with your name and address, along with a check for \$4.95 to cover S/H. Please allow 6-8 weeks to process your return.

Make check payable to Xtreme Personal Care, Inc.

Clip & Return to:

Xtreme Personal Care

32 Brunswick Ave.

Edison NJ 08817

Att: Customer Service

Customer Name \_\_\_\_\_

Return Address \_\_\_\_\_

Date Purchased \_\_\_\_\_

Store \_\_\_\_\_

Brief Description of Issue \_\_\_\_\_