

RECHARGEABLE FULL BODY HAIR TRIMMER



USE AND CARE GUIDE

(For model:CBT1-8002)

Manufactured under exclusive license of Perio Inc.© Barbasol

PLEASE RETAIN THIS USE & GUIDE FOR FUTURE REFERENCE

WARNING/IMPORTANT

- 1. Read the USE & GUIDE thoroughly before using the appliance.
- 2. Use the appliance only for purposes described in this instruction book.
- 3. For hygienic reason, the appliance should not be shared with others.
- 4. This appliance is not intended for use by persons (including children) with reduced physical sensory or mental capabilities, or lack of experience and knowledge.
- 5. Regularly check the blade condition, if signs of damage are visible, do not use.
- 6. Do not use if skin is red, irritated, inflamed, infected or blistered.
- 7. Blades will wear over time and may require replacing.
- 8. Household use only.
- 9. Do not place or store your unit in direct sunlight. Store only in a cool dry place.
- 10. Keep your appliance out of reach of children.
- 11.Do not charge the appliance where the temperature is below (32°F), or higher than (100°F), or where it will be exposed to direct sunlight or a heat source, or near excessive moisture.
- 12. Use the included USB charging cord only.
- 13. Dry the appliance completely before charging it.
- 14. Keep the USB charging cord away from water and handle with dry hands.
- 15. Grip the USB charger when disconnecting it from an AC outlet, tugging on the USB cord may damage it. Store the cord in a dry area where it will be protected from damage.
- 16. Do not pull, twist, or severely bend the cord.
- 17. Do not wrap the USB charging cord tightly around the appliance.
- 18. Do not take the housing apart.

A QUICK LOOK AT YOUR PRODUCT



CHARGING

- 1. Charging time 90 minutes, working time 90 minutes after full charge. Usage time may decrease over time.
- 2. Do not overcharge, as this may damage the appliance battery life.
- 3. Ensure appliance is switched off before charging.
- 4. Connect the charging cord on the charging connection of the appliance.
- 5. Connect the other end of the charging cord to a USB charger, current 5V 1A.
- 6. The On/Off switch light on the appliance will turn blue when charged, and it will turn red after fully charged.

HOW TO USE THE APPLIANCE

- 1. Make sure your trimmer is fully charged.
- 2. Press the On/Off switch by 2 seconds to turn your trimmer on, and the switch will show blue light.
- 3. Place the trimmer flat against your head, moving in a straight path. It is best to trim your hair when it is dry.
- 4. When finished, click the On/Off switch to turn your trimmer off before cleaning and storing.
- 5. Attach the adjustable guiding comb (size: 3/4.5/6mm) to the trimmer head to control how close a shave you get. The higher the size guide you use, the longer the remaining hair will be. Always be sure the guiding comb is locked solidly into the desired position before you start to trim.
- 6. 100% washable design, use any time in shower.

OILING THE BLADES

- 1. Apply one or two drops of lubrication oil between cutting teeth and spread out the oil evenly.
- 2. Wipe off excess oil with a cloth. Finally, point the trimmer down and away from you, and turn it on. This spreads the oil evenly and expels any excess.

CLEANING AND MAINTENANCE

- 1. Cleaning should only be done with a soft brush, such as the brush supplied with the unit.
- 2. Do not use harsh or corrosive cleaners on the units or their cutters.
- 3. Do not apply pressure or hard objects to cutters.

ENVIRONMENTAL PROTECTION

The battery within this appliance is equipped with contained substances which may result in environmental pollution.

Do not dispose of the appliance with household waste. Please recycle at a local recycling center for proper disposal.



2-Year Limited Warranty

Questions: call toll-free Barbasol Customer Service (844) 777-9601
Email Support: support@barbasolelectric.com
This appliance is covered under warranty for a period of 2 years from the purchase date. Improper use or failure to follow this use and care guide will void the warranty.
Do not return to the store. Please send a proof of purchase, return label with your name and address, along with a check for \$4.95 to cover shipping and handling. Please allow 6-8 weeks to process your return.
Make check payable to Xtreme Personal Care, Inc.
Clip & Return to:
Xtreme Personal Care
32 Brunswick Ave.
Edison NJ 08817
Attention: Customer Service
Customer Name
Return Address
Date Purchased

Brief Description of Issue _____