



Rechargeable Epilator and Shaver



USE AND CARE GUIDE

(For model: CPE1-7001)

Manufactured under exclusive license of Perio Inc. ©Pure Silk

PLEASE RETAIN THIS USE & CARE GUIDE FOR FUTURE REFERENCE

When using an electrical appliance, basic precautions should always be observed. Read all instructions before using this [appliance](#).

DANGER

To reduce the risk of electric shock:

1. Do not reach for an appliance that has fallen into water. Unplug it immediately.
2. Do not charge while bathing or in the shower.
3. Do not charge this unit near a tub, toilet or sink.

WARNING/IMPORTANT

1. Read the instruction manual thoroughly before using the [appliance](#).
2. Use the [appliance](#) only for purposes described in this instruction book.
3. For hygienic reasons, the [appliance](#) should not be shared with others.
4. This appliance is not intended for use by persons (including children) with reduced physical sensory or mental capabilities, or lack of experience and knowledge.
5. Regularly check the blade condition, if signs of damage are visible, do not use.
6. Do not use if skin is red, irritated, inflamed, infected or blistered.
7. Foils and blades will wear over time and may require replacing.
8. This product is for household use only.
9. Do not place or store your unit in direct sunlight. Store only in a cool, dry place.
10. Keep your unit out of reach of children.
11. Do not charge the shaver where the temperature is below (32°F), or higher than (100°F), or where it will be exposed to direct sunlight or a heat source, or near excessive moisture.
12. Use the included charging adaptor only.
13. Dry the [appliance](#) completely before charging it.
14. Keep the charging cord away from water and handle with dry hands.
15. Do not pull, twist, or severely bend the cord.
16. Do not wrap the charging cord tightly around the appliance.
17. Do not take the housing apart.

CHARGING

1. Prior to first use, charge for 12 hours.
2. Regular shaving will require 12 hours charging time for 60 minutes of runtime. Usage time may decrease over time.
3. Do not overcharge, as this may damage the battery life.
4. The appliance will not charge when it is switched on. Be sure to check that the “On/Off switch” is set to “Off” when charging.

USING THE APPLIANCE

EPILATOR

When you use the appliance for the first time, try it out on an area with only light hair growth. This helps you get accustomed to the epilation process.

1. Select the desired speed to switch on the appliance.
2. Select speed 1 for areas with little hair growth and for areas where bones are located directly beneath the skin, such as knees and ankles.
3. Stretch your skin with your free hand to make the hairs stand upright.

Place the appliance perpendicularly across the skin with the epilating head pointing forward. Move the appliance against the direction of hair growth at a moderate speed. Make sure the epilating discs make proper contact with the skin. Press the appliance lightly onto the skin.

SHAVING

You can use the shaving head to shave sensitive body parts, such as your underarms and bikini line. With the shaving head, you obtain a smooth result in a comfortable and gentle way.

1. Place the shaving head on the appliance and press it onto the appliance until it snaps.
2. Switch on the appliance by selecting speed 2.
3. Place the shaving head onto your skin and move the appliance slowly and smoothly against the direction of hair growth.



GENERAL DESCRIPTION

- A) Large Epilator Head
- B) Built-in Light
- C) On/Off Switch
- D) Charging Indicator Light
- E) Small Epilator Head
- F) Shaver Head
- G) Cleaning Brush

PROPER DISPOSAL FOR THE ENVIRONMENTAL

The appliance is equipped with contained substances which may result in environmental pollution.

Do not dispose of the appliance with household waste. Please properly dispose at your local recycling center.



2-Year Limited Warranty

Questions: call toll-free at 877-536-8766

Email Support: customerservice@xtremecables.com

This appliance is covered under warranty for a period of 2 years from the purchase date. Improper use or failure to follow this use and care guide will void the warranty.

Do not return to the store. Please send a proof of purchase, return label with your name and address, along with a check for \$4.95 to cover shipping and handling. Please allow 6-8 weeks to process your return.

Make check payable to Xtreme Personal Care, Inc.

Clip & Return to:

Xtreme Personal Care

32 Brunswick Ave.

Edison NJ 08817

Attention: Customer Service

Customer Name _____

Return Address _____

Date Purchased _____

Store _____

Brief Description of Issue _____