



## Wet & Dry Foil Shaver



# USE AND CARE GUIDE

(For model: CPF1-6001)

Manufactured under exclusive license of Perio Inc.©Pure Silk

## PLEASE RETAIN THIS USE & CARE GUIDE FOR FUTURE REFERENCE


### WARNING/IMPORTANT

1. Read the instruction manual thoroughly before using the device.
2. Use the shaver only for purposes described in this instruction book.
3. For the hygienic reason, the shaver should not be shared with others.
4. This appliance is not intended for use by persons (including children) with reduced physical sensory or mental capabilities, or lack of experience and knowledge.
5. Regularly check the foil condition, if signs of damage are visible, do not use.
6. Do not use if skin is red, irritated, inflamed, infected or blistered.
7. Foils and blades will wear over time and may require replacing.
8. This product is for household use only.
9. Do not place or store your unit in direct sunlight. Store only in a cool dry place.
10. Keep your unit out of reach of children.

### BATTERY REPLACEMENT

This appliance is designed for use with 2XAA batteries (1.5V, not included). If the shaver motor slows down in operation or becomes less efficient, replace the battery.


To replace the battery, take off the bottom cover as shown in the pictures below. Insert 2 (AA) batteries, observing correct polarity, and close bottom cover securely.



## SHAVING

### HOW TO USE

1. Switch on by turning the on/off switch.
2. For more precise and accurate trimming, switch the silver button to the left to position I. For large areas like the legs and under the arms, switch the silver button to the right to position II.
3. Hold the shaver at a right angle to your skin.
4. Apply gentle pressure as you move the shaver across your body, stretching the skin with your free hand. Move the shaver back and forth to achieve the desired result.
5. Applying excessive pressure will not result in a closer shave and may cause irritation or skin damage.
6. Place bikini trimmer attachment onto the cutting head to trim longer body hairs to 7mm.



## **CLEANING AND CARE**

1. To maintain your appliance, carefully clean the cutting head each time after use.
2. Remove cutting head by pulling the head away using the lateral button (see illustration).
3. Use the enclosed cleaning brush to remove all of the hairs that have collected in the cutting head. Rinse cutting head off under running tap water if necessary.
4. Put the cutting head back onto the shaver so that it clips correctly.
5. Clean the body with a soft dry cloth.
6. Clear the foil shaver after each use.

## **WEEE marking**

Waste electrical products should not be disposed of with household waste. Please recycle at a local recycling center.

