



Heated Straightening Comb



USE AND CARE GUIDE

(For model:CPH1-9002)

Manufactured under exclusive license of Perio Inc. ©Pure Silk

PLEASE RETAIN THIS USER GUIDE FOR FUTURE REFERENCE

GENERAL CAUTION

The following safety precautions should always be followed, to reduce the risk of electric shock, personal injury or fire. It is important to read all of these instructions carefully before using the product, and to save them for future reference or new users.


1. This product must only be used as intended in accordance with the enclosed operating instructions.
2. Do not carry the appliance by the power cord or pull on the cord to remove the plug from the electrical outlet.
3. Do not operate this appliance if the power cord or plug becomes damaged. A qualified electrician must always carry out any repairs that are necessary.
4. If the appliance stops unexpectedly or appears to malfunction, switch off the power supply, unplug from the electrical outlet and stop using immediately. Seek professional advice to rectify the fault or make repairs.
5. Switch off the power supply or unplug from the electrical outlet when not in use, before cleaning or changing accessories.
6. Avoid positioning the appliance where the power cord might be accidentally trapped or damaged.
7. Keep the appliance and power cord away from sources of heat, sharp objects or anything that may cause damage.
8. Ensure the appliance is switched OFF before the appliance into an electrical outlet.
9. Be aware that some surfaces may become hot. Do not touch and supervise others accordingly.
10. The unit is VERY HOT when in use. Take care to avoid contact between the hot surface of the plates and bare skin, particularly around the ears, face and neck. Care should be taken not to touch this part of the appliance when it is switched on or just after it has been turned off. ALLOW AT LEAST 30 MINUTES TO COOL DOWN BEFORE PUTTING AWAY.
11. Electrical appliances must always be stored in a secure place, out of reach of children.
12. This product is not a toy. Do not allow children or any person unfamiliar with these instructions to use the appliance.
13. Close supervision is necessary when the appliance is used near children.
14. To protect against electric shock, never allow the appliance, the power cord or plug to come into contact with water or any other liquid.
15. Never reach for any appliance that has fallen into water. Switch off the main power immediately and unplug. Do not re-use until the product has been inspected and approved by a qualified electrician.
16. Keep the appliance away from non-heat-resistant surfaces and never cover the appliance with anything (e.g. clothing or towels) when it is hot.
17. Always ensure that hands are dry before operating or adjusting any switch on the product or touching the plug and electrical outlet.

18. Keep the appliance away from water. Do not use it near or over water contained in bath, washbasins, shower etc.
19. Never leave the appliance unattended when connected to the electrical outlet. To disconnect, first ensure that all controls are in the OFF position, then remove the plug from the electrical outlet.
20. Do not use outdoors. This appliance has been designed for domestic indoor use only. Never wrap the power cord around the appliance. Do not hang up by the power cord.
21. Regularly check the power cord for wear or damage, particularly where it enters the product and the plug.
22. Keep the straightening plates clean and free of dust, dirt, styling spray and gel. Never use the appliance in combination with styling mousse, styling spray, gel etc.

EXTRA SAFETY PRECAUTIONS

1. The appliance should NEVER be stored whilst hot or whilst still plugged into the electrical outlet. Always ensure the appliance is switched off, unplugged and it has cooled down completely before storing.
2. DO NOT USE WHILE BATHING.

PRODUCT INTRODUCTION



TEMPERATURE SETTINGS:

The heated straightening comb has three heat settings-340°F, 370°F and 400°F.

- a. When the comb is switched on, it will be at the lowest heat setting of 340°F.
- b. To move through the heat settings, repeatedly press the 'ON' button.
- c. When the appliance has reached the selected temperature, the green indicator light will turn off.

HOW TO USE

NOTE: The heated straightening comb will automatically shut off after operating for 1 hour. To use it again, press the ON button and repeat the above steps.

1. Always ensure that your hair is clean, dry and combed through before using the heated straightening comb. Place a towel around your neck to protect your skin from burning. CAUTION! Do not apply hair spray or other inflammable chemicals to your hair or skin.

2. Plug the straightening comb into the electrical outlet and press the ON button located on the handle. The appliance will begin heating at the lowest temperature setting of 340°F.
3. To select the temperature, press the ON button to scroll through the different settings depending on your hair type. NOTE: A green light will appear to show the appliance is heating up.
4. After 1-2 minutes, the heated straightening comb should be ready for use.
CAUTION: Hold the straightening comb by the handle. Keep a safe distance between the appliance, your skin and eyes.
5. Separate the hair evenly at the root and put a section of hair in the comb teeth of the straightening comb.
6. Maintaining tension, slowly slide the straightening comb down the section of hair to the tip.
7. Be careful to avoid touching the comb teeth or the back of the comb with your hands or scalp since they may be hot. Note: The handle is still safe to touch.
8. Repeat the straightening process all over the head.
9. Avoid holding the appliance on one section of hair for any extended amount of time, to avoid damaging the hair.
10. To switch off the appliance, press the ON button and unplug it from the electrical socket.
11. Wait for the appliance to cool before combing.

STYLING GUIDE

Extra Volume:

1. For extra volume, hold the straightening comb at the roots of your hair for a few extra seconds, before brushing up and away from your hair.
2. You can also run the comb underneath your hair from roots to tips.

Note: Depending on the style and thickness of the hair, you may have to section off multiple upper layers.

Wavy tips:

1. Run the straightening comb from the roots of your hair to the tips.
2. As you get to the tips, place them in the comb teeth for a few seconds, and hold the comb at a slight angle.
3. Repeat until you get the desired result.

Caution! Be careful you do not leave your tips for too long in the comb teeth. Gently run the comb through your hair to avoid it getting caught in the comb teeth. Also keep the comb a safe distance away from your skin and scalp since it is heated.

Sectioning:

1. To begin take the top layer of hair and pull it into a messy bun on top of head.
2. Take the next layer and tie it up just underneath the first run-This should leave the bottom layer loose and down.

3. When the bottom layer is straightened, release the next section and straighten.
4. Continue until all hair is loose and straightened as desired.

Note: Depending on the style and thickness of the hair, you may have to section off multiple upper layers.

CLEANING AND CARE

1. Make sure the straightening comb is off. Unplug it from the electrical outlet and allow it to fully cool.
2. The straightening comb must be unplugged before cleaning.
3. Let the straightening comb cool down before touching or cleaning.
4. Carefully remove any hair from in between the comb teeth as you would with a brush.
5. Do not use any harsh detergents, abrasives, solvents or cleaners.
6. Never immerse in water or any other liquid to clean.
7. Dry thoroughly before use.
8. If damaged, do not replace the mains supply lead into the appliance-always use authorized representative or qualified technician.
9. Keep the appliance away from moisture. Do not put it in the dishwasher or microwave oven or anything of a similar nature.
10. Store the appliance on a cool and dry place.

PROPER WASTE DISPOSAL FOR THE ENVIRONMENT

Do not throw the appliance away with the normal household waste at the end of its use. Please properly dispose at your local recycling center. By doing this you will help to preserve the environment.



TROUBLESHOOTING:

ISSUE: The appliance does not work at all.

1. Check whether the power is working. If it is, check whether the electrical outlet is live by plugging in another appliance.
2. Check the power cord for damage. If the power cord is damaged, it must be replaced by the service center in order to avoid a hazard.

SPECIFICATION

Voltage: 110-240V~50/60Hz

Power: 31W



Not suitable for use in the bath or shower.

2-Year Limited Warranty

Questions: call toll-free at (844)-777-9601

Email Support: support@barbasolelectric.com

This appliance is covered under warranty for a period of 2 years from the purchase date. Improper use or failure to follow this use and care guide will void the warranty.

Do not return to the store. Please send a proof of purchase, return label with your name and address, along with a check for \$4.95 to cover shipping and handling. Please allow 6-8 weeks to process your return.

Make check payable to Xtreme Personal Care, Inc.

Clip & Return to:

Xtreme Personal Care

32 Brunswick Ave.

Edison NJ 08817

Attention: Customer Service

Customer Name _____

Return Address _____

Date Purchased _____

Store _____

Brief Description of Issue _____