

# **Massaging Facial Cleanser**



### **USE AND CARE GUIDE**

(For model:CPS1-7002)

Manufactured under exclusive license of Perio Inc. ©Pure Silk

#### PLEASE RETAIN THIS USE & CARE GUIDE FOR FUTURE REFERENCE

#### WARNING/IMPORTANT

- 1. Read the use and care guide thoroughly before using the Massaging Facial Cleanser.
- 2. Use this appliance only for purposes described in this use and care guide.
- 3. For hygienic reasons, this appliance should not be shared with others.
- 4. If signs of damage are visible, do not use and notify email support at <a href="mailto:support@barbasolelectric.com">support@barbasolelectric.com</a>.
- 5. Discontinue use if discomfort or irritation occurs. If you have a skin condition, please consult with dermatologist before using.
- 6. Do not use if skin is red, irritated, inflamed, infected or blistered.
- 7. Do not use on sunburned skin.
- 8. Do not use if you have severe skin allergies.
- 9. Do not use if you recently had cosmetic surgery.
- 10. Do not use on open cuts...
- 11. This appliance is for external use only.
- 12. This appliance is for household use only.
- 13. Do not place in direct sunlight. Store only in a cool, dry place.
- 14. Keep this appliance out of reach of children.
- 15. Use caution when using appliance near eyes, and do not use on eyelids.

#### BATTERY CARE

This appliance is designed for use with 2 (2) AAA Alkaline batteries (not included). Replace the batteries if the motor slows down in operation or becomes less efficient.

#### To insert the battery:

- 1. Open the battery compartment by bottom of device.
- 2. Insert 2 AAA Alkaline batteries (1.5V) observing correct polarity.

- 3. Replace the bottom by fitting it onto the battery compartment securely and lock it.
- 4. Replace the battery as needed.

**NOTE:** Make sure your hands and the appliance are dry when replacing the battery.

#### **PRODUCT INSTRUCTION**



#### **HOW TO USE**

#### Cleansing Mode:

- 1. Run Massaging Facial Cleanser under warm water and apply your favorite facial cleanser to the silicone pads.
- 2. Rinse face with warm water.
- 3. Press the center button once to turn on the device and activate low speed cleansing mode. For a more intense speed, press the right button (+). To return to low speed, press the left button (-).

- 4. Begin with Massaging Facial Cleanser at your chin and use gentle upward strokes as you slowly move it along your jawline to your ear and out onto your cheek. Repeat on other side of face and along forehead and nose.
- 5. To turn unit off, press center button again.

#### **CARE AND MAINTENANCE**

- 1. Do not use the Massaging Facial Cleanser for more than 3 minutes at a time.
- 2. Always rinse device with clean water after each use. Pat dry with lint-free cloth/towel.
- 3. Avoid using facial cleansers that are silicone based or grainy as they may cause damage to the silicone pad.
- 4. Avoid leaving in direct sunlight. Do not expose to extreme heat or boiling water.
- 5. Do not submerge in water.
- 6. Remove the batteries if the unit is going to be stored more than two weeks.

#### **ENVIRONMENTAL PROTECTION**

The battery used with this appliance is equipped with contained substances which may result in environmental pollution.

Do not dispose of the Massaging Facial Cleanser with household waste. Please properly dispose at your local recycling center.



## 2-Year Limited Warranty

Questions: call toll-free at (844)-777-9601 Email Support: <a href="mailto:support@barbasolelectric.com">support@barbasolelectric.com</a> This appliance is covered under warranty for a period of 2 years from the purchase date. Improper use or failure to follow this use and care guide will void the warranty. Do not return to the store. Please send a proof of purchase, return label with your name and address, along with a check for \$4.95 to cover shipping and handling. Please allow 6-8 weeks to process your return. Make check payable to Xtreme Personal Care, Inc. Clip & Return to: **Xtreme Personal Care** 32 Brunswick Ave. Edison NJ 08817 Attention: Customer Service Customer Name Return Address Date Purchased

Brief Description of Issue\_\_\_\_\_