

Rotating Cleansing Brush



USE AND CARE GUIDE

(For model:CPS1-7003)

Manufactured under exclusive license of Perio Inc. ©Pure Silk

PLEASE RETAIN THIS USE & CARE GUIDE FOR FUTURE REFERENCE

WARNING/IMPORTANT

- 1. Read this use and care guide thoroughly before using the Rotating Cleansing Brush
- 2. Use this appliance only for purposes described in this use and care guide.
- 3. For hygienic reasons, this appliance should not be shared with others.
- 4. If signs of damage are visible, do not use and notify email support at support@barbasolelectric.com.
- 5. Discontinue use if discomfort or irritation occurs. If you have a skin condition, please consult with dermatologist before using.
- 6. Do not use if skin is red, irritated, inflamed, infected or blistered.
- 7. Do not use on sunburned skin.
- 8. Do not use if you have severe skin allergies.
- 9. Do not use if you recently had cosmetic surgery.
- 10. Do not use on open cuts.
- 11. This appliance is for external use only.
- 12. This appliance is for household use only.
- 13. Do not place in direct sunlight. Store only in a cool, dry place.
- 14. Keep this appliance out of reach of children.
- 15. Use caution when using appliance near eyes, and do not use on eyelids.

BATTERY CARE

This appliance is designed for use with 4 (four) AA batteries (not included). Replace the batteries if the motor slows down in operation or becomes less efficient.

To insert the battery:

- 1. Make sure the brush is in the OFF position.
- 2. Locate the battery cap on the bottom of the unit and pull down in the direction of the arrow to open.
- 3. Install 4 AA batteries, make sure to match polarities correctly (+/- symbols on the battery ends and corresponding marks on the unit).
- 4. Replace the battery cover.

HOW TO USE

1. Choose an applicator attachment and simply snap it on the unit.



Exfoliating Face Brush: Deep cleans and exfoliates



Foam Sponge: For gentle exfoliation



Pumice Stone: For removing tough skin on feet



Exfoliating Body Brush: Apply your favorite soap or cleanser to the brush (or use without for dry brushing) and use it on your body to gently micro-massage skin while exfoliating and deep cleaning to leave skin feeling energized and radiant.

- 2. Take precaution when using around hairline to prevent hair from getting caught and tangled.
- 3. Apply your favorite soap or cleanser.
- 4. Place the appliance flat on your skin and press the "on" button on the handle.
- 5. Move over your skin using a gentle circular motion.
- 6. Limit your first use to less than one minute to test your reaction. Some redness may occur but you should not feel discomfort.

NOTE: Daily use is not recommended.

7. Use with gentle cleansers, not scrubs.

CARE AND MAINTENANCE

- 1. After every use, remove the attachment from the appliance and rinse it thoroughly.
- 2. Dry the appliance and attachments before storing.
- 3. Remove the batteries if the unit is going to be stored more than two weeks.

ENVIRONMENTAL PROTECTION

The battery used with this appliance is equipped with contained substances which may result in environmental pollution.

Do not dispose of the Rotating Cleansing Brush with household waste. Please properly dispose at your local recycling center.



2-Year Limited Warranty

Questions: call toll-free at (844)-777-9601

Email Support: support@barbasolelectric.com

This appliance is covered under warranty for a period of 2 years from the purchase date. Improper use or failure to follow this use and care guide will void the warranty.

Do not return to the store. Please send a proof of purchase, return label with your name and address, along with a check for \$4.95 to cover shipping and handling. Please allow 6-8 weeks to process your return.

Make check payable to Xtreme Personal Care, Inc.

Clip & Return to:

Xtreme Personal Care

32 Brunswick Ave.

Edison NJ 08817

Attention: Customer Service

Customer Name

Return Address

Date Purchased

Store

Brief Description of Issue_____